4 Contacts... 5 Messaging.. 6 Email... 7 Getting connected ..

8 Locate my location using GPS satellites... 9 Data backup... 10 Factory data reset.....

12 Making the most of your phone....

For more information about how to use the phone, please go to www. alcatelonetouch.com to download complete user manual. Moreover from the website you can also consult FAQ, realize software upgrade

Ouick Start Guide



11 Applications..

This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 30 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

ALCATELOnetouch

English - CIB31K0ALAAA

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

Notification pane

Notification icons More notifications are New text or multimedia Call in progress (green) Problem with text or multimedia message Bluetooth headset (blue) New Google Talk Missed cal Call on hold Call forwarding is on Data is synchronizing Uploading data Problem with sign-in or microSD card is full Download finished

No microSD card

nnected to VPN

Song is playing

Touch and drag down the Status bar or press Menu key and touch Touch and hold an empty area or press Menu key and touch Wallpaper Notifications to open the notification panel. Touch and drag up to close on the Home screen to customize wallpaper. it. From Notification panel, you can open items and other reminders indicated by notification icons or view wireless service information.

3.3 Search har

he phone provides a Search function which can be used to locate | 1.3.6 Application tab nation within applications, the phone or the web.

.3.4 Lock/Unlock your screen

To protect your phone and privacy, you can lock the phone screen by creating a variety of patterns.

.3.5 Personalize your home screen

Touch and hold an empty area or press Menu key and touch Add on the Home screen, you can add shortcuts, widgets or folders to the Home screen.

Fouch and hold the item to be repositioned to activate the Move mode, 1.3.7 Volume adjustment fouch and hold the item to be repositioned to activate the roles and process and the item to desired position, then release. Hold the icon on the left or You can set ringer, media and phone ringtone volume to your preference.

You can set ringer, media and phone ringtone volume to your preference.

Press Menu key from Home screen, select Settings Language & drag the item to desired position, incording the item to another Home screen page.

You can set ringer, media and priorite ringuists of Volume up/down key, or Settings menu. An open Wi-Fi network

USB cable

Radio is on

Phone is connected via Touch and hold the item to be removed to activate the Move mode, | .4 Applications list drag the item to the top of the Application tab, which will then turn red,

The Applications list contains all pre-embedded and newly installed

Your mobile.....

Keys and connectors



ALCATEL

Touch and hold an empty area or press Menu key and touch Themes on

To consult recently-used applications, you can press and hold the

Applications list from Home screen. Touch an icon in the window to

To access the Applications list, touch Application tab from Home screen. screen\Settings\Sound & display).

the Home screen to customize themes.

Consult recently-used applications

To return to Home screen, press Home key.

open the related application.

Touch from Home screen to enter applications list.

To return to the Home screen, press Home key.

Pick up/Send a call Enter Call Log

Return to ongoing call screen if the user navigates to other 1.2.1 Set-up applications during call.

· On Home screen, press to quick access to Settings menu or Notification panel; to launch quick search; to customize your Home screen by adding applications or changing wallnaper/theme

· On other screens, press to view options list.

Short press: Return to the Home screen or back to the central Home screen if it is extended.

Long press: Enter the recently used applications list. Go back to the previous menu or screen

Short press: End a call Lock the screen

2.1 Using Onscreen Keyboard

entering text or numbers.

s d f g h i k

your selection.

2.2 Text editing

Options list pops up

You can edit the text you have entered.

Touch and hold text you have entered

Onscreen keyboard will display automatically when a program

select input method.

keyboard\Android keyboard, a series of settings are available fo

orientation. You can also adjust it by settings (Press Menu key on Home

· Select the operation you need (Select all, Select text, Cut all

Turn the phone sideways or upright to adjust the onscreen keyboard

Adjust the onscreen keyboard orientation

Touch to enter text or numbers, touch

and hold for one or two seconds to

Touch to lock in capital letter input mode.

ong press to enter an accent of the letter

Touch to switch to symbol and numeric

Light up the screen Long press: When phone is off, power on the phone When phone is on, enter Phone options: Silent

mode, Airplane mode, Power off. Press to adjust the Volume (in call/media playing mode)

Open Search bar for searching within an application, the phone or web.

I.2 Getting started

Removing or installing the back cover



Inserting or removing the SIM card

You must insert your SIM card to make phone calls. Please power off your phone and remove battery before inserting or removing the SIM card.



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, pres and slide it out.

Installing or removing the battery



Insert and click the battery into place, then close the phone cover.

User can easily launch a call using **Phone.** Enter this menu using one of

Enter the desired number from keyboard directly or select a contact from

If you make a mistake, you can delete the incorrect digits by touching

You also can add 2-sec pause or add wait by pressing Menu key

Contacts, Call log or Favorites by touching tabs, then press Call key or

acts by pressing Menu key and touching Add to Contacts.

ich to place the call. The number you entered can be saved to

Touch Application tab from Home screen and select Phone

Unclin the cover then remove the battery

3.1 Placing a call

To hang up a call, press End key.

Press Call key, then select Phone tab.

the following two ways:

Installing and removing the memory card (MicroSD card)



move battery cover and uncover the MicroSD card protector; Insert the MicroSD card with golden contact facing downwards into the slot until t is locked. Then cover the MicroSD card protector.

To remove the microSD card while the phone is on, you must unmount the storage card (Settings\SD card, USB Mass Storage & phone storage\Unmount SD card) from the phone first, to prevent corrupting or damaging the storage card

Charging the battery



Connect the battery charger to your phone and mains socket

To reduce power consumption and energy waste, when battery • Mark/Unmark the check box to choose whether you want to take is fully charged, disconnect your charger from the plug; switch off advantage of Google's location service, then touch Next. Wi-Fi, GPS, Bluetooth or background-running applications when not in use; reduce the backlight time, etc.

3.2 Answering or rejecting a call

When you receive an incoming call, drag down the green phone icon or

You can access your call memory by pressing the Call key from the Hom-

You can view and create contacts on your phone and synchronize thes

3.3 Consulting your call memory

Contacts.....

Missed call, Dialed call and Received call.

to left or pressing End key.

1.2.3 Power off your phone 1.2.2 Power on your phone

Hold down the End key until the phone powers on. It will take some Hold down the End key from the Home screen until the phone options appear, select Power off.

1.3 Home screen

The first time you power on the phone, you are required to touch
You can bring all the items (applications, shortcuts, folders and widgets)

Touch and Hold the Android logo to begin and then sign into your Google account to you love or use most frequently to your home screen for quick access. ochronize email, contacts, calendar and other Google applications (1). Press Home key to switch to Home screen



· Enter your user name and password, then touch Sign in. If you forget your password, you can go to http://www.google.com/ to retrieve it. If you don't own a Google Account, you are prompted to create one by touching Create

Read the setup information on the screen.

seconds before the screen lights up.

Set up your phone for the first time

- · Set up the date and time then touch Next

Touch Finish setup.

This initial set up can be skipped and enabled via Settings\

In power on screen without SIM card inserted, you can also connect Touch & hold the small dots or application tab can display the thumbnails to a Wi-Fi network to sign into your Google account and to use some of extended home screen, touch the thumbnail to open it. Press **Back** key

Application availability depends on country and operator

4.1 Adding a contact

Touch Application tab on the Home screen, select Contacts, then press Menu key from contacts list screen and touch New contact

4.2 Importing and exporting contacts

From Contacts screen, press Menu key to open contacts list option menu, select Messaging. touch Import/Export, then select Import from SIM card, Export to SIM card, Import from SD card or Export to SD card.

To import/export a single contact from/to SIM card, touch the contact you want to import/export, then press Menu key and touch OK to confirm. To import/export all contacts from/to SIM card, mark Select all contacts

press **Call** key to answer. Hang up the call by dragging the red phone icon 4.3 Synchronizing contacts in multiple

accounts, depending on the applications installed on your phone.

Touch and hold a contact, then, touch Add to favorites Or touch a contact to view details then touch to add the contact to favorites (the star will turn gold in color).

You can create, edit and receive SMS and MMS with this mobile phone. To access this feature, touch Application tab from Home screen, then added.

All messages you receive or send out can only be saved in phone 5.2 Adjust message settings

Write message

On message list screen, touch New message to write text/multimedia and multimedia message.

Sending a text message

add recipients, touch **Type to compose** bar to enter the text of the the management. message. When finished, touch Send to send the text message.

You can request a delivery report for each message you send while the Enter mobile phone number of the recipient on To bar or touch 🔝 to mark is green. Messages stored on SIM card can be delete or copy by • Enter the account name and display name in outgoing emails.

An SMS of more than 160 characters will be charged as several Multimedia message settings

SMS. Specific letters (accent) will also increase the size of the Pressing the right mark to green, you can request a delivery report and SMS, this may cause multiple SMS to be sent to your recipient. read report for each message you send, automatically retrieve messages. You also can set the maximum message size.

G	GPRS connected	C	Speakerphone is on
ę,	GPRS in use	Sil	Roaming
	GPRS is disabled	ХII	No signal
E	EDGE connected		No SIM card installed
Ę	EDGE in use	'D	Vibrate mode
F	EDGE is disabled	∢ ×	Ringer is silenced
((10	Connected to a Wi-Fi network	Ā	Phone microphone is mute
*	Bluetooth is on		Battery is very low
**	Connected to a Bluetooth device	•	Battery is low
*	Airplane mode		Battery is partially drained
Ø	Alarm is set		Battery is full
all	Signal strength	Œ	Battery is charging
	GPS is on	Q	Headset connected
E 20	Receiving location data from GPS		

An SMS will be converted to MMS automatically when media files (image, Besides your Gmail account, you can also set-up external POP3 or video, audio, slides, etc.) are attached or Subject or email addresses

IMAP email accounts in your phone.

To access this function, touch Application tab from Home screen, ther An email wizard will guide you through the steps to set-up an email

Enter the email address and password of the account you want to

service provider in the phone, you will be prompted to go to the email account settings screen to enter settings manually. Or you can touch Manual setup to directly enter the incoming and outgoing settings for the email account you are setting up.

• To add another email account, you can press Menu key and touch

Add account to create.

 Enter recipient(s)'s email address in To field, and if necessary, press Menu key and touch Add Cc/Bcc to include a copy or a blind copy to the message.

• Enter the subject and content of the message.

· Press Menu key, touch Add attachment to send an attachment

Finally, touch Send.

 If you do not want to send the mail right away, you can touch Save as draft or press Back key to save a copy

IP3496_906_QG_Eng_GB_06_110411.indd

Similar to swiping, but flicking makes it move quicker.

Slide/Swipe

Touch to open applications list Touch to access Call log if you have Automatically change the screen orientation from portrait to landscape by

1.3.2 Status bar From status bar you can view both phone status (to the right side) and

1.3.1 Using the touchscreen

list will then appear on screen

To access an application, touch it with your finger.

To enter the available options for an item, touch and hold the item. For

Place your finger on the screen to drag an object to another location.

Slide the screen to scroll up and down the applications, images, web

Home screen is provided in an extended format to allow more space for notification information (to the left side). When the status bar is full, "0" icon adding applications, shortcuts etc. Slide the Home screen horizontally left will appear, touch to display hidden icons. You can touch twice an empty and right to get a complete view of the Home screen. Small dots at the area on the Home screen to hide/show the Status bar. lower left and right of the screen indicate which screen you are viewing.

turning the phone leftward to have a better screen view.

or touch an empty area to return to Home screen. You can customize the number of home screens by settings (Press Menu key on Home screen\ Settings\Sound & display).

exit last time.

Sending a multimedia message MMS enables you to send video clips, images, photos, animations, slides and sounds to other compatible mobiles and e-mail addresses.

missed call(s), or access the tab you

gold star on contact details screen.

with your Gmail contacts or other applications on the web or on your 4.5 Ouick contact

check box, then press Menu key and touch OK to confirm.

Contacts, data or other information can be synchronized from multiple

screen and touching Call log tab to view call history in categories of 4.4 Add to/remove from favorites

Select Remove from favorites on the contact's option menu or touch

When using Contacts for the first time you are required to add new contacts to phone, import contacts from SIM card to phone, or synchronize contacts from other application accounts on you replaced to the first time you are required to add new contacts to phone, or synchronize contacts from other application accounts on your phone.



memory. To consult messages stored in SIM card, press Menu key from Messaging screen, then touch Settings\Manage SIM You can adjust a set of message settings. From Messaging application

screen, press Menu key and touch Settings.

To manage messages quantities limit per conversation of text message

· Touch Next. If the account you entered is not provided by your

Press Menu key from Inbox screen, and touch Compose.

to the receiver.

2011-4-11 9:39:30





HSDPA/3G networks or WI-FI whichever is most convenient

7. Connecting to the Internet

7.1.1 GPRS/HSDPA/3G

The first time you turn on your phone with SIM card inserted it will. With the LISR cable you can transfer media files and other files between automatically configure network service: GPRS_HSDPA_or_3G

To check the network connection you are using, press Menu key o Home screen, then touch Settings\Wireless & networks\Mobile

To connect/disconnect your phone to/from the computer networks\Network operators or Access Point Names.

7.1.2 Wi-Fi

Using Wi-Fi, you can connect to the Internet when your phone is within USB is connected. range of a wireless network. Wi-Fi can be used on phone even without

Open the Notifications panel and touch **USB connected**.

To turn Wi-Fi on and connect to a wireless network

- Press Menu key from Home screen
- Touch Settings\Wireless & networks\Wi-Fi.
- Mark/Unmark the checkbox to turn on/off Wi-Fi.
- Touch Wi-Fi settings The detailed information of detected Wi-Fi Touch Turn off in the dialog that opens networks is displayed in the Wi-Fi networks section.
- Touch a Wi-Fi network to connect. If the network you selected is MicroSD card: secured, you are required to enter a password or other credentials

 • Touch Application tab from Home screen to open the applications list (you may contact network operator for details). When finished, touch

7.2 Browser...

away from the body.

• LICENCES

Using Browser, you can enjoy surfing the Web

To access this function, touch Application tab from Home screen, then

device should be positioned at least this distance away from the body. If you

is free of any metal and that it positions the phone the indicated distance

The World Health Organization has stated that present scientific information

Your telephone is equipped with a built-in antenna. For optimal operation

other than against your ear. In such circumstances the device will be compliant

with the guidelines when used with headset or usb data cable. If you are using

microSD Logo is a trademark.

and that it positions the phone at least 1.5 cm away from the body

ID B017760

and/or its Affiliates.

another accessory ensure that whatever product is used is free of any metal

hands-free kit to keep the device away from the head and body.

For more information you can go to www.alcatelonetouch.com

available on the following site: http://www.who.int/peh-em

you should avoid touching it or degrading it.

To go to a web page

On Browser screen touch the LIRI how at the top enter the address of the web page, then touch Go.

More options on the web page

Touch the Menu, you have more options, such as, add new window, add bookmark, select text, and so on.

7.3 Connecting to a computer via USB

your phone's MicroSD card and the computer

- To connect your phone to the computer
- Use the USB cable that came with your phone to connect the phone to a USB port on your computer. You will receive a notification that the
- Touch Mount in the dialog that opens to confirm that you want to transfer files.

To disconnect:

- Unmount the microSD card on your computer
- Open the Notifications panel and touch Turn off USB storage

To locate data you have transferred or downloaded in your

- Touch FileManager

Body-worn SAR testing has been carried out at a separation distance of General information

does not indicate the need for any special precautions for the use of mobile

On our website, you will find our FAQ (Frequently Asked Questions)

www.alcatelonetouch.com

Other trademarks and trade names are those of their Your telephone is identified by an IMEI (phone serial number) shown on

telephone or specific operator services

are not using an approved accessory ensure that whatever product is used Internet address; www.alcatelonetouch.com

Additional information about electromagnetic fields and public health are languages according to availability on our server

The Bluetooth word mark and logos are owned by our website: www.alcatelonetouch.com

TCT Mobile Limited and its affiliates is under license. **Protection against theft** (1)

As mobile devices offer a range of functions, they can be used in positions quad-band (850/900/1800/1900 MHz).

All data you have downloaded are stored in FileManager, where you can view media files (videos, photos, music and others), rename files, install oplications into your phone, etc.

Your telephone is a transceiver that operates on GSM/GPRS/EDGE i

There may be certain differences between the user manual descriptio

Contact your network operator to check service availability

nd the phone's operation, depending on the software release of your

Locate my location using GPS satellites......

To activate your phone's global positioning system (GPS) satellite • Touch Settings\Privacy\Back up my settings

- Press Menu key from Home scree
- Touch Settings\Location & security\Use GPS satellites
- Mark the checkbox

by the operator exclusively.

the packaging label and in the phone's memory. We recommend that you Therefore, TCT Mobile shall not be held responsible for the lack of

6 # and keep it in a safe place. It may be requested by the police or its availability depends on the country and the operator of the purchases

ur operator if your telephone is stolen. This number allows your mobile TCT mobile reserves the right at any time to add or remove Third Party

number the first time you use your telephone by entering * # availability of one or more applications wished for by the purchaser, as

e to be blocked preventing a third person from using it, even with Materials from its handsets without prior notice; in no event shall TCI

When open Maps, you can find your location:



Use your phone's GPS satellites receiver to pinpoint your location within 20-40 seconds to identify your precise location.

Data backup...

This phone enables you to back up your phone's settings to Google

If you replace your phone, the settings you've backed up are restored onto the new phone the first time you sign in with your Google Account. To activate this function

Press Menu key from Home screen

- Mark the checkhox

Activated this function, a wide variety of settings are backed up, including Communicate with friends your Wi-Fi passwords, bookmarks, a list of the applications you've installed Exchange messages or emails with friends the words you've added to the dictionary used by the onscreen keyboard and most of the settings that you configure with the Settings application. • Track you location, view traffic situations, search for locations and get If you deactivated this option, you stop backing up your settings, and any navigation information to your destination existing backups are deleted from Google Servers. Download more applications from Android Market

Factory data reset

- Press Menu key from Home screen Touch Settings\Privacy\Factory data reset

an accuracy as close as several meters ("street level"). The process of Phone reset will erase all of your personal data from internal phone alcatelonetouch.com. accessing the GPS satellite and setting your phone's precise location for storage, including information about your Google Account, any other the first time will require up to 5 minutes. You will need to stand in a place accounts, your system and application settings, and any downloaded | 2. | PC suite with a clear view of the sky and avoid moving After this, GPS will only need applications. Resetting the phone does not erase any system software updates you've downloaded or any files on your microSD card, such as music or photos. If you reset the phone in this way you're prompted to • Contacts re-enter the same kind of information as when you first started Android.

Applications....

applications are available for your convenience

With the built-in applications, you can

It allows you to easily import photos from PC or the handset and organiz them in different albums for better manageme

With this phone, some build-in Google applications and other third party

It allows you to insert video files from PC for playback and then upload

to handset folder

It allows you to quickly search your favorites in PC, manage the ultimate Library and enjoy the easiest digital jukehox in your own mobile way

Outlook Express and handset

Supported Operating Systems

12.2 One Touch Upgrade

Windows XP/Vista/Windows 7

It allows you to import downloaded mobile applications and have them installed into your handset upon synchronizatio

It allows you to synchronize the Contacts and Calendar in Outlook/

Using One Touch Upgrade tool you can update your phone's software

personal data using PC Suite before upgrading.

the update process. We recommend you backup your

For more information about these applications, please check user manual. It allows you to organize Handset files with just a few clicks and files on online: www.alcatelonetouch.com the Handset can be at where you want them to be

Making the most of your phone

You can download software upgrade for free from the website: www

The PC suite includes:

your phone is used.

and more

It allows you to back up contact entries so that you don't have to worry
Your phone's software will now have the latest software. about losing, breaking, switching phone or changing service providers.

It frees you from painstakingly inputting text on the keypads. All of your messages are easily accessible and well-organized

We recommend that you read this chapter carefully before using your phone. to +55°C. sequence of improper use or use contrary to the instructions contained is temporary and not serious.

TRAFFIC SAFFTY:

Safety and use......

Given that studies show that using a mobile phone while driving a vehicle Do not drop, throw or bend your mobile phone. constitutes a real risk, even when the hands-free kit is used (car kit, headset...), Do not paint it. drivers are requested to refrain from using their mobile when the vehicle is

Use only batteries, battery chargers, and accessories which are recommended When driving do not use your phone and headphone to listen to music or to

model. TCT Mobile Limited and its affiliates disclaim any liability for damage the radio. Using a headphone can be dangerous and forbidden in some areas. caused by the use of other chargers or batteries. When switched on, your phone emits electromagnetic waves that can interfere Remember to make back-up copies or keep a written record of all important with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To information stored in your phone. Some people may suffer epileptic seizures or blackouts when exposed to

- do not place your phone on top of the dashboard or within an airbag deployment area.
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

CONDITIONS OF USE

You are advised to switch off the telephone from time to time to optimis

Switch the phone off before boarding an aircraft. Switch the phone off when you are in health care facilities, except in designated

areas. As with many other types of equipment now in regular use, mobile elephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Take a minimum of a 15-minute break hourly Switch the phone off when you are near gas or flammable liquids Strictly obey Play in a room in which all lights are on. all signs and instructions posted in a fuel depot, petrol station, or chemical Play at the farthest distance possible from the screen plant, or in any potentially explosive atmosphere. When the phone is switched on, it should be kept at least 15 cm from any

Download One Touch Upgrade from the website and install it on your PC. Launch the tool and update your phone by following the step by step medical device such as a pacemaker, a hearing aid or insulin pump, etc. In nstructions (refer to the User Guide provided together with the tool). particular when using the phone, you should hold it against the ear on the opposite side to the device, if any, To avoid hearing impairment, pick up the call before holding your phone to All personal information will be permanently lost following

your ear. Also move the handset away from your ear while using the "handsfree" mode because the amplified volume might cause hearing damage. Do not let children use the phone and/or play with the telephone and accessories without supervision. When replacing the cover please note that your phone may contain substances

My mobile phone can not connect to a network Try connecting in another location

Check with your operator that your SIM card is valid.

Try connecting at a later time if the network is overloaded

Verify with your operator that your SIM card is 3V. I.8V compatible

Make sure the chip on your SIM card is not damaged or scratched

Launch touch screen calibration (Touch Application tab-->Select

For international calls, check the country and area codes

network (check for overloaded or unavailable network)

Make sure your mobile phone is connected to a network, and that the

Check your subscription status with your operator (credit, SIM card

Check your subscription status with your operator (credit, SIM card

Verify the network coverage with your operator

Try selecting the available network(s) manually

Make sure the SIM card has been correctly inserted

the old 5V SIM cards cannot be used

Touch screen does not respond

Unable to make outgoing calls

Make sure your phone is not locked

network is not overloaded or unavailable

Your caller has concealed his/her number.

Unable to receive incoming calls

Make sure you have not barred outgoing calls

SIM card arrow

TSCalibration)

valid, etc.)

valid, etc.)

Always handle your phone with care and keep it in a clean and dust-free place.

that could create an allergic reaction. Mobile Limited and its affiliates.

The sound quality of the calls is not optimal

rest for several hours before playing again

syndrome, or other musculoskeletal disorders.

stop the game and see a doctor.

damage the listener's hearing.

Check the signal strength level I am unable to use the features described in the manual

You can adjust the volume during a call by means of the Volume key

Check with your operator to make sure that your subscription

Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY

should never rely only on your phone for emergency calls

phone or enabling a flashing-lights feature on your phone.

Do not play or use a flashing-lights feature if you are tired or need sleep.

Do not open, dismantle or attempt to repair your mobile phone yourself.

includes this service I am unable to add a contact in my directory

personal directories)

Make sure that your phone memory is not full; delete some contacts or save the contacts in the product directory (i.e. your professional or

My callers are unable to leave messages on my voicema

Contact your network operator to check service availability

I cannot access my voicemail Make sure your operator's voicemail number is correctly entered

Try later if the network is busy

I am unable to send and receive MMS Make sure you have dialled a valid number and press the (key

Check your phone memory available as it might be full Contact your network operator to check service availability and check

- Verify the server centre number or your MMS profile with your
- The server centre may be swamped; try again late "No service" is displayed

MMS parameters

- You are outside of the network coverage area. Make sure your mobile phone is switched on and connected to a
 - I have already entered 3 incorrect PIN codes Contact your network operator to obtain the PUK code (Personal

Unblocking Key) I am unable to connect my phone to my computer

Install Alcatel's PC suite first of all

- Open Notification panel to check if the PC Suite Agent has activated Check that you have marked the checkbox of USB debugging in
- Check that your computer system meets the requirements for Alcatel's

PC Suite installation

nditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). Please note that you must respect the laws and regulations in force i

The manufacturer's recommended operating temperature range is -10°C your jurisdiction or other jurisdiction(s) where you will use your m The chargers designed for your mobile phone meet with the standard for The manufacturer disclaims any liability for damage, which may result as a At over 55°C the legibility of the phone's display may be impaired, though this telephone. Pursuant to such laws and regulations, it may be strictly forbidde safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in to take photographs and/or to record the voices of other people or any o one jurisdiction may not work in another jurisdiction. They should be used Emergency call numbers may not be reachable on all cellular networks. You their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole respons for this purpose only ensure that prior authorisation be obtained, if necessary in order to re private or confidential conversations or take a photograph of another pe Proof of compliance with international standards (ICNIRP) or with European the manufacturer, the seller or vendor of your mobile phone (includin Directive 1999/5/EC (R&TTE) is required of all mobile phone models before operator) disclaim any liability which may result from the improper use they can be put on the market. The protection of the health and safety for by TCT Mobile Limited and its affiliates and are compatible with your phone the user and any other person is an essential requirement of these standards

BATTEDY.

Before removing the battery from your phone, please make sure that the phone is switched off Observe the following precautions for battery use

- flashing lights, or when playing video games. These seizures or blackouts may Do not attempt to open the battery (due to the risk of toxic fumes and occur even if a person never had a previous seizure or blackout. If you have
- experienced seizures or blackouts, or if you have a family history of such Do not puncture, disassemble or cause a short-circuit in a battery, occurrences, please consult your doctor before playing video games on your - Do not burn or dispose of a used battery in household rubbish or store it
- at temperatures above 60°C. Parents should monitor their children's use of video games or other features

 Batteries must be disposed of in accordance with locally applicable the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is that incorporate flashing lights on the phones. All persons should discontinue environmental regulations. Only use the battery for the purpose for which 2 W/K

use and consult a doctor if any of the following symptoms occur: convulsion, it was designed. Never use damaged batteries or those not recommended by Tests for SAR are conducted using standard operating positions with the eye or muscle twitching, loss of awareness, involuntary movements, or TCT Mobile Limited and/or its affiliates. This symbol on your telephone the battery and the accessories

means that these products must be taken to collection points at the end of their life: Municipal waste disposal centres with specific bins for these items of equipment

- Collection bins at points of sale. If your hands, wrists, or arms become tired or sore while playing, stop and

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

If you continue to have sore hands, wrists, or arms during or after playing, In European Union countries: hese collection points are accessible free of charge

When you play games on your phone, you may experience occasional All products with this sign must be brought to these collection points. discomfort in your hands, arms, shoulders, neck, or other parts of your body. In non European Union jurisdictions:

I am unable to download new files

Delete some files

Check for free space of your MicroSD card

Follow the instructions to avoid problems such as tendinitis, carpal tunnel ltems of equipment with this symbol are not to be thrown into ordinary bins are not to be thrown into ordinary bins. if your jurisdiction or your region has suitable recycling and collection facilities; values stated above. This is because, for purposes of system efficiency and to Prolonged exposure to music at full volume on the music player may instead they are to be taken to collection points for them to be recycled.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN device is automatically decreased when full power is not needed for the call. INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE

The lower the power output of the device, the lower its SAR value. Set your phone volume safely. Use only headphones recommended by TCT INSTRUCTIONS.

Mains powered chargers will operate within the temperature range of:

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE

Your mobile device is a radio transmitter and receiver. It is designed

not to exceed the limits for exposure to radio waves (radio frequency

electromagnetic fields) recommended by international guidelines. Th

and include a substantial safety margin designed to assure the safety of all

bands. The highest SAR values under the ICNIRP guidelines for this device

Maximum SAR for this model and conditions under which

Body-worn SAR

Rody-worn SAR

minimize interference on the network, the operating power of your mobile

Head SAR

Head SAR

e radio wave exposure guidelines use a unit of measurement known as

nitting at its highest certified power level in all tested frequence

0,4 W/kg

0.5 W/kg

0.23 W/kg

guidelines were developed by an independent scientific organi

persons, regardless of age and health.

model are:

UMTS 2100 + Wi-Fi

GSM 1800 + Wi-Fi +

Check your subscription status with your operator The phone can't be detected by others via Bluetooth

Make sure that Bluetooth is turned on and your mobile phone is visible to other users

How to make your battery last longer Make sure you followed the complete charge time (minimum 3 hours)

After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an

- exact indication
- Switch on the backlight upon request Extend email auto-check interval as long as possible
- Exit background-running applications if they are not being used for a Deactivate Bluetooth, Wi-Fi, or GPS when not in use

and is used under license by TCT Mobile Limited.

ALCATEL is a trademark of Alcatel-Lucent

the right to alter material or technical specification without prior notice.

© Copyright 2011 TCT Mobile Limited

The warranty period may vary depending on your country.

time standby time and total service life will depend on the conditions of use and network configuration. Batteries being considered expendable supplies. the specifications state that you should obtain optimal performance for you phone during the first six months after purchase and for approximately 200 more recharge

(2) The life of a rechargeable mobile phone battery in terms of conversation

This warranty shall not apply to defects to your phone and/or accessory

Troubleshooting... Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where Before contacting the aftersales department, you are advised to follow

TCT Mobile Limited.

Mobile Limited or its affiliates or your vendor. 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods. chemical products, download of files, crash, high voltage, corrosion

handset or in interaction with any other devices of the purchaser. To replaced or repaired, as appropriate. Repaired phone and accessories

There are no express warranties, whether written, oral or implied, other

your country or jurisdiction. In no event shall TCT Mobile Limited or any of its affiliates be liable for • Press the 👝 key indirect, incidental or consequential damages of any nature whatsoever, • Remove the battery and re-insert it, then switch the phone back on

incidental or consequential damages, or limitation of the duration of My mobile phone will not charge properly implied warranties, so the preceding limitations or exclusions may not

You are advised to switch off the phone from time to time to maintain

. fou are advised to fully charge () the battery for optimal operation

and carry out the following checks:

Check the battery charge level Check the battery contacts, remove and reinstall your battery, the

· Check that your keypad is locked when you are not using your mobile

Make sure your battery is inserted. It must be inserted before plugging

Make sure that your battery is not completely discharged; the battery

use such applications and Third Party Materials.

This handset may contain materials, including applications and software Your phone is warranted against any defect or malfunctioning which Hot Line Number: see "TCT Mobile Services" leaflet or go to our in executable or source code form, which is submitted by third parties may occur in conditions of normal use during the warranty period of materials in this handset are provided "as is", without warranty of any original invoice. design to indicate the need for any special precadulary for the case of implied, including the implied warrantees. On our website, you will find our requiring to the case of implied, including the implied warrantees of implied, including the implied warrantees. Section, You can also contact us by e-mail to ask any questions you may of merchantability, fitness for a particular purpose or use/third party kind, whether express or implied, including the implied warranties Batteries (a) and accessories sold with your phone are also warranted 3) Modification or repair performed by individuals not authorised by TCT application, interoperability with other materials or applications of the the date of purchase as shown on your original invoice. An electronic version of this user guide is available in English and other languages according to availability on our server:

Unchaser and non-infringement of copyright. The purchaser undertakes that TCT Mobile has complied with all quality obligations incumbent upon it as a manufacturer of mobile devices and handsets in complying with Intellectual Property rights.TCT Mobile will at no stage be responsible phone with your proof of purchase. the maximum extent permitted by law TCT Mobile disclaims all liability are entitled to a one (1) month warranty for the same defect. Repair or for any claims, demands, suits or actions, and more specifically - but not replacement may be carried out using reconditioned components offering limited to - tort law actions, under any theory of liability, arising out of the equivalent functionality. use, by whatever means, or attempts to use, such Third Party Materials. This equipment is in compliance with the essential requirements and Moreover, the present Third Party Materials, which are provided free of other relevant provisions of Directive 1999/5/EC. The entire copy of the charge by TCT Mobile, may be subject to paid updates and upgrades in Declaration of Conformity for your telephone can be obtained through the future; TCT Mobile waives any responsibility regarding such additional costs, which shall be borne exclusively by the purchaser. The availability of the applications may vary depending on the countries and the operators where the handset is used; in no event shall the list of possible applications and software provided with the handsets be considered as an undertaking

from TCT Mobile; it shall remain merely as information for the purchase

Mobile be held responsible by the purchaser for any consequences that

such removal may have on the purchaser regarding the use or attempt to

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne Warranty....

for inclusion in this handset ("Third Party Materials"). All third party twelve (12) months (1) from the date of purchase as shown on your 2) Connection to any equipment not supplied or not recommended by

for the inability or failure of the Third Party Materials to operate on this. If the defect is confirmed, your phone or part thereof will be either have been removed or altered.

This warranty covers the cost of parts and labor but excludes any other costs

Some countries/states do not allow the exclusion or limitation of indirect, • Check the battery charge level

Your phone will not be repaired in case labels or serial numbers (IMEI) • Press . until the screen comes on

including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed

Avoid storing large amounts of data in your phone as this may affect the performance of your phone.

My mobile phone can not switch on

turn your phone back on than this printed limited warranty or the mandatory warranty provided by My mobile phone has not responded for several minutes

· Make sure you are using an Alcatel battery and charger provided in

in the charger charge indicator can take several minutes

Make sure charging is carried out under normal conditions (0°C - +40°C)

• Check that you have subscribed to this service with your operator When abroad, check that the electrical current is compatible

> I cannot find my contacts Make sure your SIM card is correctly inserted Import all contacts stored in SIM card to phone

Make sure you have not forwarded incoming calls The caller's name or number does not appear when a call is

Settings\Applications\Development\USB debugging

All rights reserved

TCT Mobile Limited reserves



IP3496_906_QG_Eng_GB_06_110411.indd 2





trademarks of Google Inc.

logo, Google Search, Google Maps, Gmail, YouTube Android Market, Google latitude and Google Talk are

one touch 906 Bluetooth QD

TouchPal™ and CooTek™ are trademarks of Shanghai

HanXiang (CooTek)Information Technology Co., Ltd

The Wi-Fi Logo is a certification mark of the Wi-Fi Google, the Google logo, Android, the Android



2011-4-11 9:39:31